

Ford Focus MK2

Front Lower Tie Bar



Tools Required: 18MM



Job time approx. 10-20 Mins

Step 1.

Lift your car either on a car lift or using a jack and jack stands.

Step 2.



Loosen both front control arm bolts leave the left bolt sticking out about 2cm as shown below and fully remove the other side.



Step 3.

Slip the left side of the tie bar into the bolt previously left loose then align the right side of the bar upto the control arm and reinsert the bolt. Then tighten both bolts down.

