

## Ford Focus MK2

### Rear Lower Tie Bar



**Tools Required: 15MM** (15MM ratchet spanner helps)



**Job time approx. 15-30 Mins**

## **Step 1.**

**Lift your car either on a car lift or using a jack and jack stands.**

## **Step 2.**

**Remove the inner tie arm bolt on each side**



## Step 3.

**Place the bar between the two tie arm mounting points then use the existing bolts through the brace then through the tie arm and tighten both the bolts down.**

